


Firmware version checking procedure



(Screenshot for version 1.00)

Insert a blank formatted media in the camera. Turn on your "Camera" while holding down the [DISP/BACK] button. The number will displayed "CURRENT" showing the camera's current firmware version.

When you check firmware of a lens, you need to attach the lens to a camera body.

After checking the firmware version, press the [MENU/OK] button and then turn off your camera.