This list of devices have been tested with the V-Mic D3 Pro. This list is not a complete list of all devices that can work (or don't work) with the V-Mic D3 Pro.

DEVICE	COMPATIBLE
Deity Connect BP-TX	Yes
Zoom H1 Zoom H1n Zoom H2 Zoom H4n (3.5mm Jack) Zoom Q2n Zoom Q4n Zoom F1 Zoom EXH6	Yes
Tascam DR10 series Tascam DR40 Tascam DR 22WL	Requires 3rd Party TRS Cable
Sennheiser G1, G2, G3, G4 Sennheiser AVX Sennheiser XS	Yes
Azden XD-Pro Azden WMBB Pro	Yes
RODELink TX-Belt RODELink TX-XLR	Yes, +13cm separation
Blackmagic BMPCC Blackmagic BMPCC4k Blackmagic Micro Studio Camera 4 Blackmagic Micro Cinema Camera	Requires 3rd Party TRS Cable
iPhone X iPhone Xs iPhone Xs MAX IPHONE 8	Requieres Headphone adapter
IPHONE 7IPHONE 6S IPHONE 6S PLUS IPHONE 6 PLUS IPHONE 6	Yes
Samsung Tab Series Samsung Galaxy Series Samsung Note 4, 5, 7, 8, 9	Yes
Google Pixel Google Pixel XL	Yes
Google Pixel 2 Google Pixel 2 XL Google Pixel 3 Google Pixel 3 XL	USB-C Headphone Adapter
Kinefinity MAVO Kinefinity MAVO LF Kinefinitty TERRA	Yes
RED DSMC2 RED Hydrogen	Yes
GoPro Hero 1 GoPro Hero 2 GoPro Hero 3 GoPro Hero 3+ GoPro Hero 4, 4+Black GoPro Hero 5 Black GoPro Hero 5 Session GoPro Hero 6	With USB to microphone adapter
Sony a6300 Sony a6500 Sony a77 II Sony a7 Sony a7R Sony a7S Sony a7 II Sony a7 III Sony a7R II Sony a7S II Sony a7R III Sony a7 III Sony RX10 M4 Sony a9 Sony a99	Yes
Sony AX700 Sony NX80 Sony PXW Z90V	Yes
Sony FS5 / FS5 ii Sony FS7 Sony Z90	Requires D-XLR adapter
Lumix S1 Lumix S1R Lumix HC-V800 Lumix DMC-FZ2500 Lumix DMC-FZ1000 Lumix G85 Lumix G9 Lumix GH3 Lumix GH4 Lumix GH5, GH5s	Yes
Fuji X-Pro 2	2.5mm male to 3.5mm female adapter
Fuji X-T2 Fuji X-T3	Requires 3rd Party TRS Cable
EOS 550D/Rebel T2i EOS 600D/Rebel T3i EOS 650D/Rebel T4i EOS 700D/Rebel T5i EOS 750D/Rebel T6i EOS 800D/Rebel T7i EOS 100D/Rebel SL1 EOS 200D/Rebel SL2 EOS 1000D/Rebel XS* Canon EOS 60D Canon EOS 60Da Canon EOS 70D Canon EOS 77D Canon EOS 80D Canon EOS 7D Canon EOS 7D Mark II Canon EOS 5D Mark II Canon EOS 5D Mark III Canon EOS 5D Mark IV Canon EOS 5Ds Canon EOS 5Ds R Canon EOS 6D Canon EOS 6D Mark II Canon EOS-1D X Canon EOS-1D X Mark II Canon EOS-1D CCanon EOS RCanon EOS RPCanon M50	Yes
Canon XA-10, XA-11, XA-15, XA-20, XA-25, XA-30, XA-35 Canon C100 Canon C300 Canon C500	Requires D-XLR adapter
Nikon D750 Nikon D850 Nikon D610 Nikon D5600 Nikon D500 Nikon Z6 Nikon Z7	Yes
Olympus E-M1X Olympus E-M1ii Olympus E-M1 Olympus E-M5ii Olympus E-M5iii Olympus E-M10ii	Requires 3rd Party TRS Cable
Lumia 950 Nexus 6 Vivo X20 VIVO X6 OPPO Huawei Mate 10 Huawei Mate 10 pro Huawei Mate 8 Huawei horo V9 Huawei horo V8 Huawei horo 8 Huawei nova 1 Huawei horo play XIAO MI 5 XIAO MI Red Mi 5plus XIAO MI Red Mi 3 XIAO MI Red Mi NOTE3 XIAO MI 6 ZTX nubia Z17 MEIZU PRO 7 Coolpad C09 360 vizza MEIZU PRO 6	Not with default Video App; Works with Cinema FV-5 app;
Huawei Honor 5x MEIZU Blue NOTE 6 Nikon D7000 Canon T3/100D Canon VIXIA HFR500 Canon VIXIA HFG30, HFG30, G10 ARRI MINI Canon Legria HF G25 ATMOS NINJA V	NO