Data Cable Connection

Connect the camera and the stabilizer with the camera control cable and HD HDMI cable that come standard with the stabilizer.



ZHIYUN Cable Collocation Illustration

Mark	①	②			③		④	⑤
Connector Type	USB 3.0 to USB Mini	USB 3.0 to USB Micro			USB 3.0 to Multi		USB 3.0 to USB Mini 8P + Φ2.5mm plug	USB 3.0 to Type-C
Mark	B				A			C
Connector Type	HDMI Mini to HDMI Mini				HDMI Mini to HDMI Micro			HDMI Mini to HDMI
Camera Model	Canon			Nikon	Sony		Panasonic	
	5D3	5D4	1DX2	D850	A7M3	A7RM3	GH4	GH5
Photo	√	√	√	√	√	√	√	√
Video	√	√	√	√	√	√	√	√
Live Preview	√	√	√	√	×	×	×	×
AV	√	√	√	√	√	√	×	√
TV	√	√	√	√	√	√	×	√
ISO	√	√	√	√	√	√	×	√
EV	√	√	√	√	√	√	×	√
Digital Zoom	×	×	×	×	√	√	×	×
AF	√	√	√	√	√	√	√	√
Manual Electronic Follow Focus	√	√	√	√	×	×	×	×
Image Transmission	√	√	√	√	√	√	√	√